# PRICE LIST  OF PARTS

## DeVRY MODEL "16-2830"

### 16 mm. Sound-on-Film Projector

**(Also Referred to as Model RS-ND30)**

## PARTS PRICE LIST OF DeVRY PROJECTOR - MODEL "16"

| PART NUMBER | PART NAME | DESCRIBED ON PAGE | SHOWN ON PAGE | UNIT LIST PRICE |
|---|---|---|---|---|
| 31 | COVER, aperture case | 25 | 9 | .45 |
| 159 | CAN, oil | 24 | Not shown | .30 |
| 231 | CLEAT, lamp bracket | 24 | Not shown | .20 |
| 242 | PLUG, female twist lock (on A. C. Power Cable) | 27 | Not shown | 2.10 |
| 401 | LAMP, 6 V, 2 Amp. exciter | 26 | Not shown | .50 |
| 413 | LAMP, G.E. 115 V, 2 C. P. | 26 | Not shown | .30 |
| 414 | LAMP, 4 V, ¾ Amp. exciter | 26 | 32 | .65 |
| 462 | §LAMP, 750 W, 115 V, (G. E.) | 26 | 35 | 4.10 |
| 465 | §LAMP, 750 W, 120 V, (R) | 26 | Not shown | 4.10 |
| 476 | §LAMP, 1000 W, 115 V, (G. E.) | 26 | Not shown | 6.00 |
| 626 | SCREW, special 6-32 | 28 | 34 | .35 |
| 726 | SCREW, 8-32 fillister head | 28 | 31-34 | .05 |
| 737 | SCREW, gulmite | 28 | 34 | .15 |
| 1151 | SOCKET, prefocus lamp | 28 | 38 | 2.45 |
| 1679 | CUP, oil | 25 | 33 | .25 |
| 1689 | ARMATURE, E. M. C. motor | 24 | Not shown | 11.50 |
| 1786 | CORD, 25 ft. power extension (Accessory item) | 25 | Not shown | 9.60 |
| 1787 | CORD, 50 ft. power extension (Accessory item) | 25 | Not shown | 15.00 |
| 1788 | CORD, 75 ft. power extension (Accessory item) | 25 | Not shown | 20.00 |
| 1851 | *HANDLE, case (see footnote) | 26 | 31 | 1.35 |
| 1853 | PAD, with machine screw | 27 | Not shown | .10 |
| 1854 | PAD, with wood screw | 27 | Not shown | .10 |
| 1871 | OIL, 2 ounce bottle | 27 | Not shown | .30 |
| 1896 | LOCK, case door | 27 | 31 | 1.50 |
| 2952 | WRENCH 8-32 Allen head | 29 | Not shown | .15 |
| 2980 | GREASE, 2 oz. jar, shuttle | 25 | Not shown | .30 |
| 3126 | PLUG, P. E. cable | 27 | 37 | 3.25 |
| 3826 | CONDENSER, mounted inside motor | 25 | Not shown | .30 |
| 3886 | BRUSHES, E. M. C. motor | 24 | 15 | .50 |
| 3887 | BRUSHES, E. M. C. governor | 24 | 15 | .25 |
| 3888 | GOVERNOR, E. M. C. (A. C.) | 25 | 15 | 12.00 |
| 4028 | RHEOSTAT, 50 ohm motor | 28 | 38 | 3.25 |
| 4065 | CONDENSER, .5 mfd. motor | 25 | 15 | .45 |
| 4106 | PLUG, 4 pin motor | 27 | 15-35 | .45 |
| 4108 | RESISTOR, 25 ohm motor | 28 | 15 | .55 |
| 4152 | PLUG, male power | 27 | Not shown | .20 |
| 4285 | KNOB, black rheostat | 26 | 9 | .25 |
| 4459 | CELL, CE-4 photo electric | 24 | 32 | 5.50 |
| 5678 | ROLLER, filter | 28 | 34 | 1.50 |
| 5839 | REEL, 1600 ft. 16 mm. | 28 | Not shown | 2.75 |
| 5844 | REEL, 400 ft. 16 mm. | 28 | Not shown | .75 |
| 6613 | LENS, 1" coated projection (Accessory item) | 26 | Not shown | 26.50 |
| 6616 | LENS, 1½" coated projection (Accessory item) | 26 | Not shown | 26.50 |
| 6619 | LENS, 2½" coated projection (Accessory item) | 26 | Not shown | 26.50 |
| 6622 | LENS, 3" coated projection (Accessory item) | 26 | Not shown | 26.50 |
| 6624 | LENS, 3½" coated projection (Accessory item) | 26 | Not shown | 26.50 |
| 6626 | LENS, 4" coated projection (Accessory item) | 26 | Not shown | 26.50 |
| 6945 | LENS, 2" coated projection (Standard lens furnished) | 26 | 7 | 26.50 |
| 7094 | PIN, rewind | 27 | 9 | .05 |
| 8509 | WASHER, motor base | 29 | 35 | .10 |
| 8516 | BELT, motor drive | 24 | 35 | 1.15 |
| 8532 | TUBE, tilting device | 29 | 5 | 1.50 |
| 8533 | LOCK, tilting tube | 27 | Not shown | .40 |
| 8534 | NUT, tilting bracket | 27 | 5 | .80 |
| 8544 | SCREW, quick set, knurled | 28 | 35 | .30 |

§ Add 7½% Excise Tax to the unit price on projection lamps.

* 1851 is a leather handle. If plastic handle is desired order No. 9282 handle at $ .75 with (2) 9280 handle posts at $ .20 per set.

**We Reserve the Right to Change Prices and Specifications Without Prior Notice** **MINIMUM NET ORDER $1.00**

Parts Listed Above are Fully Described and Identified in the DeVry "16-2830" Operating Manual & Parts Catalog

# PARTS PRICE LIST OF DeVRY PROJECTOR - MODEL "16"

| PART NUMBER | PART NAME | DESCRIBED ON PAGE | SHOWN ON PAGE | UNIT LIST PRICE |
|---|---|---|---|---|
| 8556 | RING, spring wire | 28 | Not shown | .05 |
| 8564 | PLATE, dial | 27 | 9 | .70 |
| 8591 | BLOCK, lamp socket | 24 | Not shown | .35 |
| 8606 | SCREW, knurled thumb | 28 | 13 | .10 |
| 8610 | SCREW, knurled thumb | 28 | 7-30 39 | .10 |
| 8630 | SOUND DRUM | 25 | 32-34 | 11.00 |
| 8632 | STUD, sound drum roller | 29 | 7-34 | .35 |
| 8634 | STUD, spring anchor | 29 | 34 | .10 |
| 8635 | LENS, sound, slit | 26 | 32-34 | 25.60 |
| 8640 | KNOB, tension roller | 26 | 7-34 | .40 |
| 8706 | KNOB, idler | 26 | 7 | .10 |
| 8715 | SPACER, film shoe | 29 | 33 | .10 |
| 8716 | PIN, shoe hinge | 27 | 33 | .20 |
| 8736 | SCREW, button head | 28 | 33 | .35 |
| 8737 | WASHER, arm tension | 29 | 33 | .15 |
| 8760 | COVER, sound drum | 25 | 32 | .45 |
| 8766 | SCREW, exciter lamp lock | 28 | 31-32 34-39 | .35 |
| 8776 | COVER, P. E. cell | 25 | 32-34 | .90 |
| 8798 | CORD, 10 ft. power | 25 | Not shown | 4.50 |
| 8803 | CONDENSER, coated | 25 | 30 | 18.00 |
| 8805 | LAMPHOUSE ASSEMBLY | 26 | 30 | 33.00 |
| 8809 | SHAFT, shutter | 28 | 37 | 1.25 |
| 8811 | SPROCKET, feed and shaft | 29 | 7 | 4.75 |
| 8818 | SHUTTLE & CAM | 28 | 33 | 8.25 |
| 8826 | IDLER, feed and take-up | 26 | 7 | 3.25 |
| 8880 | SPROCKET, take up and shaft | 29 | 7 | 4.75 |
| 8900 | ARM, upper reel | 24 | 5-33 | 14.75 |
| 8901 | ARM, lower reel | 24 | 5-33 | 13.00 |
| 8902 | ARM, plunger | 24 | 5-33 | 1.25 |
| 8903 | BAFFLE, shutter | 24 | 33 | .35 |
| 8904 | BASE, cover | 24 | 33 | 1.80 |
| 8905 | BEARING, stabilizer | 24 | 7 | 13.80 |
| 8906 | BEARING, sprocket | 24 | 37 | 12.00 |
| 8907 | BLOCK, film shoe | 24 | 33 | 1.50 |
| 8908 | BRACKET, lamp yoke | 24 | 38 | .80 |
| 8909 | BRACKET, motor socket | 24 | 38 | .40 |
| 8910 | BRACKET, pressure shoe sliding | 24 | 39 | 1.60 |
| 8911 | BRACKET, face plate | 24 | 36 | .85 |
| 8912 | BRACKET, exciter lamp | 24 | 39 | .85 |
| 8913 | BRACKET, lamp support | 24 | 39 | .85 |
| 8914 | BRACKET, tension roller | 24 | 34 | 5.75 |
| 8915 | BRACKET, pressure plate | 24 | 13-39 | 1.60 |
| 8916 | CABLE, photo cell | 24 | 36 | 10.50 |
| 8917 | HOLDER, projection lens | 26 | 39 | 17.15 |
| 8918 | HOLDER, slit lens | 26 | 34 | 2.70 |
| 8919 | *CASE, projector, (see footnote), Geib | 24 | 9 | 50.00 |
| 8920 | CATCH, lamphouse | 24 | 30 | .30 |
| 8921 | RECEPTACLE, twist lock exciter | 28 | 9 | 1.35 |
| 8922 | CONTACT, exciter lamp | 25 | 32 | .85 |
| 8923 | COVER, switch plate | 25 | 35 | .60 |
| 8924 | COVER, exciter lamp | 25 | 31-34 | 4.60 |
| 8925 | COVER, P. E. socket box | 25 | 37 | 2.20 |
| 8926 | COVER, aperture frame | 25 | 7-30 | 1.85 |
| 8927 | FLYWHEEL, sound filter | 25 | 36 | 6.75 |
| 8928 | FLYWHEEL, stabilizer | 25 | 36 | 4.50 |
| 8929 | FRAME, catalin plate | 25 | 9 | 1.35 |
| 8930 | GEAR, shutter | 25 | 36-37 | 2.40 |
| 8931 | GEAR, take-up | 25 | 36 | 10.15 |
| 8932 | GEAR, micarta feed | 25 | 36 | 7.35 |
| 8933 | GLASS, red window | 25 | Not shown | .85 |
| 8934 | GUARD, chain | 25 | 36 | 1.75 |
| 8935 | GUARD, slit light | 25 | 7 | .35 |
| 8936 | HANDLE, lamphouse | 26 | 30 | .40 |
| 8937 | HOLDER, condenser | 26 | 30 | .80 |
| 8938 | HOLDER, exciter lamp | 26 | 39 | 11.25 |
| 8939 | IDLER, take-up chain | 26 | 36 | 4.20 |
| 8940 | LEVER, filter roller | 26 | 34 | .60 |
| 8941 | LEVER, film gate | 26 | 7-13 39 | 1.15 |
| 8942 | LEVER, framer | 26 | 31-33 | 1.05 |
| 8943 | MOTOR, complete E. M. C. drive | 27 | 15 | 45.00 |
| 8944 | SOCKET, 4 pin motor | 28 | 38 | .40 |
| 8945 | HOLDER, oil can | 26 | Not shown | .40 |
| 8946 | OILING, centralized | 27 | 37 | 3.60 |
| 8947 | PAD, foot | 27 | Not shown | .15 |
| 8948 | PANEL, switch | 27 | 38 | 51.90 |
| 8949 | PARTITION, lamphouse end | 27 | 35 | 1.70 |
| 8952 | PARTITION, lamphouse | 27 | 30-35 | 4.25 |

* When ordering a new PROJECTOR CASE please give the SERIAL NUMBER of the PROJECTOR.

**We Reserve the Right to Change Prices and Specifications Without Prior Notice** **MINIMUM NET ORDER $1.00**

Parts Listed Above are Fully Described and Identified in the DeVry "16-2830" Operating Manual & Parts Catalog

# PARTS PRICE LIST OF DeVRY PROJECTOR - MODEL "16"

| PART NUMBER | PART NAME | DESCRIBED ON PAGE | SHOWN ON PAGE | UNIT LIST PRICE |
|---|---|---|---|---|
| 8953 | PLATE, idler latch | 27 | 7 | .35 |
| 8954 | PLATE, motor base | 27 | 15 | 4.00 |
| 8955 | PLATE, pressure | 27 | 13-39 | 2.35 |
| 8956 | SOUND HEAD COMPLETE | 29 | 34 | 109.00 |
| 8957 | PLATE, motor condenser-resistor | 27 | 15 | 3.00 |
| 8958 | STUD, shuttle | 29 | Not shown | .60 |
| 8959 | PULLEY, drive | 27 | 36 | 11.65 |
| 8960 | PULLEY, drive rewind | 27 | 31 | 2.00 |
| 8961 | PULLEY, take-up rewind | 27 | 5 | 1.40 |
| 8962 | PULLEY, motor | 27 | 15 | 1.50 |
| 8963 | RECEPTACLE, male lock | 27 | 9-38 | 1.20 |
| 8964 | RECEPTACLE, female | 27 | 9-38 | .50 |
| 8965 | REFLECTOR | 28 | Not shown | 4.65 |
| 8966 | RING, inside glass | 28 | Not shown | .50 |
| 8967 | RING, inside vent. | 28 | Not shown | 1.05 |
| 8968 | RING, sound drum | 28 | 34 | 2.90 |
| 8969 | ROLLER, guide idler | 28 | 7 | 1.50 |
| 8970 | ROLLER, sound idler | 28 | 7-34 | 1.65 |
| 8971 | ROLLER, tension | 28 | 7-34 | 1.45 |
| 8972 | SHAFT, case reel | 28 | Not shown | 1.50 |
| 8973 | SHIELD, sound light | 28 | 34 | 1.05 |
| 8974 | SHUTTER | 28 | 33 | 1.00 |
| 8975 | SLIDE, motor guide | 28 | 35 | .35 |
| 8976 | SLIDE, lamphouse stop | 28 | 35 | 1.05 |
| 8977 | SLIDE, lamphouse guard | 28 | 30 | 1.15 |
| 8978 | SOCKET, lamp (with bracket) rear | 28 | 38 | .50 |
| 8979 | SOCKET, lamp (with bracket) front | 29 | Not shown | .50 |
| 8980 | SPRING, lamphouse release | 28 | 30 | .25 |
| 8981 | SPRING, filter tension | 29 | 37 | .20 |
| 8982 | SPROCKET, take-up chain | 29 | 36 | 4.25 |
| 8983 | BRACKET, motor guard | 24 | 35 | 1.00 |
| 8984 | STUD, switch cover | 29 | 38 | .10 |
| 8985 | STUD, idler roller | 29 | 33 | .50 |
| 8986 | STUD, sound drum lever | 29 | 34 | .60 |
| 8987 | STUD, tension arm | 29 | Not shown | .70 |
| 8988 | STUD, sound roller | 29 | 34 | .80 |
| 8989 | STUD, framer lever | 29 | 7 | .55 |
| 8990 | TILTING ASSEMBLY | 29 | 5 | 10.40 |
| 8991 | LEG, tilting | 26 | 5 | .85 |
| 8992 | WING, right lamphouse | 29 | 30 | .40 |
| 8993 | WING, left lamphouse | 29 | 30 | .40 |
| 8994 | ROLLER, film stud | 28 | 31 | 1.50 |
| 8995 | LENS, aspheric condenser | 26 | Not shown | 4.25 |
| 8996 | LENS, plano-convex condenser | 26 | Not shown | 4.75 |
| 8997 | FRAME, aperture plate | 25 | 33 | 6.85 |
| 9004 | MOTOR — E. M. C. less base, fans, etc. | 27 | 15 | 30.00 |
| 9013 | SCREEN, ventilator | 28 | 9 | .80 |
| 9016 | GUARD, motor | 25 | 30 | 3.25 |
| 9018 | COVER, pilot lamp | 25 | 7 | .95 |
| 9032 | STUD, guard spacer | 29 | 35 | .25 |
| 9033 | BELT, take-up spring | 24 | 31-33 | .25 |
| 9041 | NUT, knurled exciter | 27 | 32-39 | .25 |
| 9045 | BRACKET, lamp casting | 24 | 32-39 | 4.00 |
| 9046 | SCREW, lamp clamp | 28 | 32-39 | .15 |
| 9049 | SCREW, exciter adjusting | 28 | 32-39 | .10 |
| 9050 | CRANK, rewind | 25 | Not shown | 2.25 |
| 9051 | WASHER, shuttle stud | 29 | Not shown | .20 |
| 9052 | SPRING, shuttle stud | 29 | Not shown | .05 |
| 9057 | SWITCH, lamp and motor | 29 | 9-38 | 2.50 |
| 9058 | FAN, front motor | 25 | 15-30 35 | 6.00 |
| 9059 | FAN, rear motor | 25 | 15 | 7.80 |
| 9077 | SCREW, shuttle | 28 | 33 | .20 |
| 9081 | CHAIN, take-up drive | 24 | 36 | 5.80 |
| 9086 | SHAFT, cam | 28 | 37 | 3.10 |
| 9113 | SPRING, tension | 29 | 34 | .10 |
| 9134 | PLATE, aperture tension | 27 | 13-33 | 11.75 |
| 9146 | BEARING, lower reel arm needle | 24 | Not shown | .35 |
| 9150 | SHAFT, reel take-up | 28 | 33 | 2.70 |
| 9249 | SWITCH sound, silent | 29 | 9-38 | .75 |
| 9514 | SPRING, pressure arm | 29 | 34 | .15 |

## ACCESSORY ITEMS

| | | | |
|---|---|---|---|
| 1786 | CORD, 25' power, extension | Not shown | 7.00 |
| 1787 | CORD, 50' power, extension | Not shown | 9.50 |
| 1788 | CORD, 75' power, extension | Not shown | 11.50 |
| 7471 | TABLE, projector | Not shown | 25.00 |
| 9245 | COVER, canvas, projector case | Not shown | 9.00 |

**We Reserve the Right to Change Prices and Specifications Without Prior Notice** **MINIMUM NET ORDER $1.00**

Parts Listed Above are Fully Described and Identified in the DeVry "16-2830" Operating Manual & Parts Catalog

# PARTS PRICE LIST OF DeVRY AMPLIFIER-SPEAKER PARTS

## (Model 2830 Amplifier -- Model 4429 Loudspeaker)

| PART NUMBER | PART NAME | DESCRIBED ON PAGE | SHOWN ON PAGE | UNIT LIST PRICE |
|---|---|---|---|---|
| 3812 | CONDENSER, .04 mfd., 600 V. | 20 | 21 | .15 |
| 3813 | CONDENSER, .03 mfd., 600 V. | 20 | 21 | .15 |
| 3825 | CONDENSER, .25 mfd., 400 V. | 20 | 21 | .35 |
| 3826 | CONDENSER, .002 mfd., 600 V. | 20 | 21 | .25 |
| 3835 | CONDENSER, .001 mfd., 600 V. | 20 | 21 | .30 |
| 3836 | CONDENSER, .01 mfd., 600 V. | 20 | 21 | .30 |
| 3847 | RESISTOR, 1000 ohm, ½ watt | 20 | 21 | .15 |
| 3859 | CONDENSER, .00025 mfd., 400 V. | 20 | 21 | .15 |
| 3862 | CONDENSER, .05 mfd., 600 V. | 20 | 21 | .20 |
| 3869 | POTENTIOMETER, 1 megohm | 20 | 21 | .60 |
| 3940 | PLUG, twist lock | 20 | 21 | 1.00 |
| 3964 | RECEPTACLE, fuse (post) | 20 | 21 | .45 |
| 3999 | CORD & PLUG, A. C. line | 12 | 12 | 2.00 |
| 4015 | RESISTOR, 5000 ohm, 1 W. | 20 | 21 | .25 |
| 4016 | RESISTOR, 10,000 ohm, 1 W. | 20 | 21 | .20 |
| 4017 | RESISTOR, 50,000 ohm, .5 W. | 20 | 21 | .15 |
| 4020 | RESISTOR, 1 megohm, .5 W. | 20 | 21 | .10 |
| 4026 | RESISTOR, 20,000 ohm, 1 W. | 20 | 21 | .25 |
| 4035 | RESISTOR, 500 ohm, .5 W. | 20 | 21 | .10 |
| 4037 | RESISTOR, 150,000 ohm, .5 W. | 20 | 21 | .10 |
| 4038 | RESISTOR, 3,000 ohm, .5 W. | 20 | 21 | .10 |
| 4053 | CONDENSER, .005 mfd., 600 V. | 20 | 21 | .60 |
| 4076 | PLUG, 2 pin speaker | 20 | 21 | .75 |
| 4085 | FUSE, 3 amp. | 20 | 21 | .06 |
| 4157 | CONDENSER, 10 mfd., 25 V. | 20 | 21 | .50 |
| 4197 | RESISTOR, 500,000 ohm, .5 watt | 20 | 21 | .15 |
| 4198 | RESISTOR, 100,000 ohm, .5 watt | 20 | 21 | .15 |
| 4205 | RESISTOR, 250,000 ohm, .5 watt | 20 | 21 | .15 |
| 4217 | CONDENSER, .1 mfd., 400 volt | 20 | 21 | .25 |
| 4235 | CONDENSER, .0005 mfd., 400 volt | 20 | 21 | .30 |
| 4301 | TUBE, 6 J 7 | 20 | 21 | 1.80 |
| 4310 | TUBE, 5 U 4 G | 20 | 21 | 1.35 |
| 4327 | TUBE, 6 L 6 | 20 | 21 | 2.65 |
| 4330 | TUBE, 6 V 6 | 20 | 21 | 2.65 |
| 4361 | TUBE, 6 S N 7 | 20 | 21 | 1.80 |
| 4379 | RESISTOR, 2000 ohm, 5 watt | 20 | 21 | .40 |
| 4519 | SWITCH, with plate | 20 | 21 | .60 |
| 4569 | JACK microphone-phono | 20 | 21 | .35 |
| 8474 | COIL, oscillator, KIT ASSEMBLY | 20 | 21 | 2.00 |
| 8477 | RECEPTACLE, P. E. C. sound input, KIT ASSEMBLY | 20 | 21 | 2.00 |
| 8478 | POTENTIOMETER, dual, KIT ASSEMBLY | 20 | 21 | 2.00 |
| 8479 | POTENTIOMETER, 500,000 ohm, KIT ASSEMBLY | 20 | 21 | 1.00 |
| 8481 | RESISTOR, 10,000 ohm, 25 watt, KIT ASSEMBLY | 20 | 21 | .90 |
| 8482 | RESISTOR, 1500 ohm, 25 watt, KIT ASSEMBLY | 20 | 21 | 1.00 |
| 8483 | RESISTOR, 130 ohm, 25 watt, KIT ASSEMBLY | 20 | 21 | 1.00 |
| 8484 | RECEPTACLE, speaker, KIT ASSEMBLY | 20 | 21 | 1.00 |
| 8485 | SOCKET, 6 V 6 tube, KIT ASSEMBLY | 20 | 21 | .35 |
| 8486 | SOCKET, 5 U 4 tube, KIT ASSEMBLY | 20 | 21 | .35 |
| 8487 | SOCKET, 6 J 7 tube, KIT ASSEMBLY | 20 | 21 | .40 |
| 8488 | SOCKET, 6 S N 7 tube, KIT ASSEMBLY | 20 | 21 | .35 |
| 8719 | CONDENSER, KIT ASSEMBLY | 20 | 21 | 4.75 |
| 8889 | *CASE, amplifier, KIT ASSEMBLY (see footnote) | 20 | 21 | 32.50 |
| 8891 | SOCKET, 6 L 6 tube, KIT ASSEMBLY | 20 | 21 | .35 |
| 8892 | SPEAKER, KIT ASSEMBLY | 20 | 21 | 20.00 |
| 8893 | TRANSFORMER, power, KIT ASSEMBLY | 20 | 21 | 16.50 |
| 8894 | TRANSFORMER, output, KIT ASSEMBLY | 20 | 21 | 11.75 |
| 8895 | CHOKE, KIT ASSEMBLY | 20 | 21 | 3.80 |
| 8896 | TRANSFORMER, input, KIT ASSEMBLY | 20 | 21 | 10.75 |
| 8998 | CONDENSER, KIT ASSEMBLY | 20 | 21 | 1.35 |

### ACCESSORY ITEMS

| | | | |
|---|---|---|---|
| 2974 | SPEAKER, extension, in case, ASSEMBLY | Not shown | 60.00 |
| 3916 | CORD, speaker extension, 50 foot, 2 wire | Not shown | 7.50 |
| 4125 | CONNECTOR, 2 pin, female for 3916 extension cord | Not shown | .95 |
| 4398 | CORD, speaker extension, 100 foot | Not shown | 10.00 |
| 9246 | COVER, canvas, amplifier case | Not shown | 9.00 |

* When ordering a new AMPLIFIER CASE please give the SERIAL NUMBER of the AMPLIFIER.

**We Reserve the Right to Change Prices and Specifications Without Prior Notice** **MINIMUM NET ORDER $1.00**

Parts Listed Above are Fully Described and Identified in the DeVry "16-2830" Operating Manual & Parts Catalog


## DeVRY CORPORATION -- 1111 Armitage Ave., Chicago 14, Ill., U.S.A.

Form 16 P. L. (2-47) Printed in U.S.A.